



Z-Clip French Cleat Installation Instruction

SKU:

ZCP1, ZCP1-3, ZCP1-6, ZCP2, ZCP2-3, ZCP2-6, ZCP3, ZCP3-3, ZCP3-6

1

Attach mounting bracket to back of the Art Work.

Attach mounting bracket to the wall using drywall anchors, wall screws, and level.

For best results use level and drill pilot holes.

2

Wall

Art Work

ANCHOR

SCREW

SCREW

3

4

Mirrors
Pictures
Shelves
Cabinets
Panels

